


SETTING UP A DECON ROOM



The decontamination setting above complies with both Essential Quality Requirements and Best Practice.

Practices may increase the number of washer disinfectors, ultrasonic baths and sterilisers if capacity and service continuity dictates.

The use of an Ultrasonic Bath, and Washer Disinfector is optional (to the standard of EQR). Where such a cleaner is not provided, handling difficulties will be reduced by siting the washing sink near to the rising sink or by combining both sinks through the installation of a double-bowl sink assembly.

Decontamination Cycle

